



Woodblock Multiclamp Mount Kit - Model MWBM

Installation Directions

1. Insert the black rubber grommets into the holes in the clamp.
2. Tape the template to the back or bottom of the woodblock, depending on how you want to orient the mount.
3. Drill pilot holes with a 5/32" drill. Do not drill into the woodblock slot!
4. Screw the mount to the woodblock so it compresses the rubber grommet, but not so tightly that the mount touches the woodblock. The rubber grommet must be a buffer between the woodblock and mount.



cut on dotted line and tape to woodblock

